

SeIRO[®] MPS-36 - pH Stable Membrane

Nanofiltration Spiral Module Series – 2540, 4040

PRODUCT DESCRIPTION

Membrane Chemistry:	Proprietary composite nanofiltration membrane
Membrane Type:	pH stable nanofiltration membrane
Molecular Weight Cut-Off (MWCO):	1000 Dalton
Construction:	Spiral wound element
Major Applications:	Acid and caustic recovery, Product concentration
Permeate Tube Material:	CPVC

SPECIFICATIONS

Part Number	Model	Rejection [%]		Permeate Flow gpd (m ³ /day)	Feed Spacer mil (mm)	Membrane Area ft ² (m ²)
		Glucose / Sucrose	NaCl			
0770036	MPS-36 2540 A2X	30 / 50	10	2,535 (9.6)	30 (0.8)	17.2 (1.6)
0770194	MPS-36 4040 A2X	30 / 50	10	9,350 (35.4)	30 (0.8)	60.3 (5.6)


*Test Conditions: RO water at 440 psi (30 bar), 86°F (30°C). Feed solution for rejection tests is 3% glucose / 3% sucrose or 5% NaCl

OPERATING AND DESIGN INFORMATION*

Typical Operating Pressure:	220-510 psi (15-35 bar)
Maximum Temperature:	122°F (50°C)
Allowable pH - Continuous Operation:	1-13
Allowable pH - Clean-In-Place (CIP):	1-13
Maximum Pressure Drop Per Element:	10 psi (0.7 bar)
Maximum Pressure Drop Per Vessel (5 in Series):	50 psi (3.5 bar)

*Consult KSS Process Technology Group for specific applications.

NOMINAL DIMENSIONS



Model	A		B		C		D	
	inches	mm	inches	mm	inches	mm	inches	mm
MPS-36 2540	40.0	1016	2.4	61	0.75	19.0	1.0	25.4
MPS-36 4040	40.0	1016	3.9	99	0.75	19.0	1.0	25.4

OPERATING GUIDELINES

Membrane Characteristics:

SelRO® Composite nanofiltration membrane in a spiral wound configuration, with superior pH and temperature stability.

Operating Limits:

- **Operating Pressure:** Maximum operating pressure for SelRO® MPS-36 is 510 psi (35 bar). Actual operating pressure is dependent upon system flux rate, as well as feed, recovery and temperature conditions.
- **Permeate Pressure:** Maximum allowed permeate pressure is 3 psi (0.2 bar).
- **Differential Pressure:** Maximum differential pressure limit is 10 psi (0.7 bar) per element. Maximum differential pressure for any length vessel is 50 psi (3.5 bar).
- **Operating and Cleaning Temperature:** The operating and cleaning temperature is limited to 122°F (50°C) for A2 elements (CPVC permeate tube).
- **pH:** Allowable range for continuous operation is 1-13. When a stainless steel permeate tube is used, corrosive acids should be avoided.

Water Quality for Cleaning and Diafiltration:

- **Turbidity:** Maximum feed turbidity is 1 NTU.
- **Guidelines:** For more details, please consult with KSS Process Technology Group.

Chlorine and Chemical Exposure:

- It is not recommended to expose the MPS-36 membrane to chlorine or other oxidants, as it may affect the membrane performance.
- Sodium metabisulfite (without catalysts such as cobalt) is the preferred chemical to eliminate free chlorine or other oxidizers in the feed.

- It is not recommended to expose the MPS-36 membrane to organic solvents, such as alcohol, acetone, etc.

Feed Flow Rate:

Maximum and minimum flow rate for the MPS-36 spiral module are as follows:

- **2540** Minimum 2 gpm (7.5 liter/min)
- **2540** Maximum 5 gpm (19 liter/min)
- **4040** Minimum 6 gpm (22 liter/min)
- **4040** Maximum 17 gpm (65 liter/min)

Actual feed flow rate is dependent upon system flux rate, feed characteristics, fouling tendency and system design.

Element Handling:

- **Cleaning Materials:** Depending on the nature of the feed, cleaning will include low pH cycle, high pH cycle, and surfactant blends. Consult KSS regarding the cleaning of your membranes.
- **Lubricants:** For element installation, use only water or glycerin to lubricate seals. The use of petroleum or vegetable-based oils or solvents may damage the element and will void any warranty.
- **Storage:** Refer to KSS "Element Handling and Storage" bulletin.

Service and Ongoing Technical Support:

KSS has an experienced staff of professionals available to assist end-users and OEMs for optimization of existing systems and support with the development of new applications. KSS also offers a complete line of membrane pretreatment, cleaning, and maintenance chemicals.

The information contained in this publication is believed to be accurate and reliable, but is not to be construed as implying any warranty or guarantee of performance. We assume no responsibility, obligation or liability for results obtained or damages incurred through the application of the information contained herein. Refer to Standard Terms and Conditions of Sale and Performance Warranty documentation for additional information

KOVALUS SEPARATION SOLUTIONS™, LLC • 850 Main Street, Wilmington, MA 01887

Main: +1-978-694-7000 • Toll Free: +1-888-677-5624

For complete contact information and listing of our global locations, visit www.kovalus.com

©2023 KOVALUS SEPARATION SOLUTIONS™, LLC. All rights reserved worldwide. For related patent and trademark information, visit www.kovalus.com/legal.