

# ROMICON® XM50 3" Hollow Fiber Cartridges

Industrial Hollow Fiber Ultrafiltration Module for Wastewater Treatment

PRODUCT DESCRIPTION					
Membrane Chemistry:	Acrylonitrile co-polymer				
Membrane Type:	XM				
Molecular Weight Cut-off:	50,000 Dalton (nominal)				
<b>Housing Construction:</b>	Polysulfone				
Seal:	Ероху				

PRODUCT SPECIFICATIONS							
Part Number	Model	Active Membrane Area ft² (m²)					
0720091	HF, 3025-15.0-45-XM50	15.0 (1.4)					
0720126	HF, 3043-26.5-45-XM50	26.5 (2.5)					

# **OPERATING AND DESIGN INFORMATION\***

Maximum Inlet Pressure: 30 psi @ 77°F (2.1 bar @ 25°C)

Maximum Operating Temperature (at pH 8.0):113°F (45°C)Maximum Permeate Side Back Pressure:20 psi (1.4 bar)

 Maximum Feed Side Pressure Drop:
 25 psi @ 113°F (1.7 bar @ 45°C)


 Allowable pH:
 1.5 – 13.0 @ 113°F (45°C)

<sup>\*</sup>Consult KSS Process Technology Group for specific applications.

FEED FLOW VS. PRESSURE DROP									
Circulation Flow KPN 0720091 (3025)			ion Flow 126 (3043)	Pressure Drop/Module					
gpm	m³/hr	gpm	m³/hr	psi	bar				
19	4.3	24	5.4	10	0.7				
23	5.2	29	6.6	15	1.0				
26	5.9	35	8.0	20	1.4				

Data based on water at 77° F and a specific gravity of 1.0. Circulation rates exhibit variances of 15%.

# **NOMINAL DIMENSIONS**



	Α		В		C		D		Permeate	Process
Model	inches	mm	inches	mm	inches	mm	inches	mm	Connection	Connection
3025	4.0	102	25	635	22 <sup>15</sup> / <sub>16</sub>	583	3	76	1 ½" T/C	3" T/C
3043	4.0	102	43	1092	40 15/16	1040	3	76	1 ½" T/C	3" T/C

#### **OPERATING GUIDELINES**

## **Membrane Incompatibility**

Prior to exposing the membranes to any chemical, the chemical should be reviewed by KSS. Aside from the listed chemicals, synthetic coolants, semi-synthetic coolants, kerosene, naphtha, gasoline, floc polymers, etc., may affect membrane performance.

## Chemicals that should be avoided include the following:

- Aprotic Solvents (e.g., Dimethyl Formamide, Dimethyl Acetamide, N-Methyl Pyrolidine)
- Chlorinated Solvents (e.g., Methylene Chloride, chloroform, Carbon Tetrachloride)
- Ketones (e.g., Acetone, Diacetone Alcohol)
- Silicones or Silicone based Defoamers (e.g., Siloxane)

#### **Service and Ongoing Technical Support**

KSS has an experienced staff of professionals available to assist end-users and OEMs with optimization of existing systems and to support the development of new applications. Along with the availability of supplemental technical bulletins, KSS also offers a complete line of cleaning chemicals.

The information contained in this publication is believed to be accurate and reliable, but is not to be construed as implying any warranty or guarantee of performance. We assume no responsibility, obligation or liability for results obtained or damages incurred through the application of the information contained herein. Refer to Standard Terms and Conditions of Sale and Performance Warranty documentation for additional information